

Aquaporin Inside® Forward Osmosis Technology



WHAT IS FORWARD OSMOSIS (FO)?

Aquaporin Inside® FO is a gentle process that transports water across a semi-permeable FO membrane while effectively retaining any dissolved solutes on the feed side. The osmotic pressure difference between a solution of higher concentration (draw solution) and a solution of lower concentration (feed solution) drives the FO process as shown in the figure.


FO applications can be broadly categorized into 3 types, depending on the desired outcomes:

- ✓ Concentration of valuable products or dewatering of liquid waste stream
- ✓ Dilution of the draw solution
- ✓ Production of clean water

Combining FO with a draw solution recovery system such as reverse osmosis (RO), results in a hybrid system capable of delivering all 3 desired outcomes.

Feed solution
Low osmotic pressure
(low TDS)

Draw solution
High osmotic pressure
(high TDS)




● Valubles, nutrients & aromas

● Water

HOW DOES IT WORK?

When water molecules pass through the FO membrane, the feed solution becomes increasingly concentrated while diluting the draw solution in the process. Draw recovery is a necessary step in the FO process to maintain a constant osmotic driving force as well as to “liberate” water trapped in the draw solution.

Aquaporin recommends the use of RO to regenerate the draw solution whenever possible due to its’ long track record and competitive CAPEX & OPEX. Other draw recovery methods such as high brine concentrator or thermal evaporators can be employed when RO is not feasible.



FO APPLICATIONS

VALUABLES CONCENTRATION



Coconut juice & milk concentration



Coffee and tea extract dewatering



Flavors and fragrances concentration



Textile dye concentration
Enzymes concentration

WASTEWATER DEWATERING



Textile wastewater dewatering



Dairy wastewater concentration



ZLD in semiconductor wastewater



Scrubber wastewater dewatering
Steel pickling

PROCESS OPTIMIZATION



Pre-treatment to multi stage flash thermal desalination



Seawater desalination



Pressure-retarded osmosis (PRO)



Fertilizer driven forward osmosis (FDFO)

WHY IS FO RELEVANT?





Challenges with current concentration technology (RO & evaporators)

- ✓ Loss of valuables, nutrients and aromas during heating process in evaporators
- ✓ Energy intensive operations (high OPEX)
- ✓ Frequent cleaning due to fouling and scaling





How can FO solve your problems?


- ✓ Protects valuables, nutrients, and aromas during processing by utilizing nature's own water filtration technology to drive water extraction gently without the need for hydraulic pressure and thermal input
- ✓ Improved operational stability and product water quality when treating industrial wastewater with high-COD/high-BOD/high-TOC load in applications where traditional membrane technologies fail
- ✓ Significantly reduced OPEX/CAPEX cost in zero liquid discharge (ZLD) applications

Valuables concentration

	 VALUABLES RETENTION	 PRODUCT QUALITY	 INITIAL INVESTMENT	 ENERGY REQUIREMENTS
FO-RO hybrid system	High levels of valuables retention	Gentle on valuables, High quality concentrate	Mid	Low - RO for draw recovery (3-4 kWh/m ³)
Evaporators	Loss of volatiles/aromatic compounds by heating	Degradation of heat-sensitive valuables, Loss of nutritive & sensory quality	High	Extremely high (30-60 kWh/m ³)


Wastewater dewatering

	 CONTAMINANTS REJECTION	 PERMEATE QUALITY	 INITIAL INVESTMENT	 OPERATIONAL STABILITY
FO-RO hybrid system	Highest rejection to contaminants	Higher	Mid	High low fouling propensity
Reverse osmosis	High rejection to contaminants	High	Mid	Medium higher fouling propensity



KICK-STARTING YOUR FO JOURNEY

Road to FO commercialization



What is needed in an FO process?

Three steps to design your FO process:

- 1 Choose a suitable FO membrane form factor
- 2 Select the type and size of the systems
- 3 Choose your draw solution and recovery method

FO technical support

Aquaporin's expert FO teams will support you technically at every step of the way from lab-scale all the way to full-scale system implementation.

Please contact Goldfinch Engineering System (our distributor in India) at mktg@goldfinchengg.com or tel. no. 91-22-25801521/ 29/46/ 55 for more information.

About Aquaporin

Aquaporin A/S is a global water technology company located in Kongens Lyngby, Denmark.

Aquaporin is dedicated to revolutionizing water purification with its' novel membrane technology.

The main goal of Aquaporin is to develop the Aquaporin Inside® technology which is capable of separating and purifying water from all other compounds.

The Aquaporin Inside® platform uses biotechnological principles in a technological context, which is a novel upcoming field with large commercial perspectives. This is a field where Denmark has taken an early global lead.

About Goldfinch

Goldfinch is a turnkey solution provider in Industrial Wastewater Treatment with three decades of experience. Goldfinch has executed hundreds of projects for almost all type of industries in all sectors within India and in Africa. Repeat orders demonstrate high level of customer satisfaction in terms of technical capability and the services. Goldfinch considers that fighting pollution is not merely a commercial venture; in fact, it serves to fulfill a social obligation. Goldfinch is a well-knit family of highly qualified personnel working under its wings, which have spread far and wide to include big corporate names into its Clients list. Well defined working philosophy, is the backbone of Goldfinch's growth.

GOLDFINCH™
One-stop Environmental Solution...

Aquaporin A/S
Nymøllevej 78
2800 Kongens Lyngby
Denmark

Phone: +45 8230 3082
sales@aquaporin.com
www.aquaporin.com

Aquaporin Asia Pte Ltd
1 Cleantech Loop, #02-14
Cleantech One
Singapore 637141

Phone: +65 8722 1002
sales@aquaporin.asia
www.aquaporin.asia

Aquapoten Company Ltd.
12A Shougang International Trade Tower
No. 60 Xizhimen North Street
Haidian District, Beijing, 100082, China

Phone: +86-10-52408461
business@aquapoten.com
www.aquapoten.com



WHAT IS NEEDED IN AN FO PROCESS?

Three steps to design your FO process

- 1 Choose a suitable FO membrane form factor
- 2 Select the type and size of the systems
- 3 Choose your draw solution and recovery method

1 FO membrane form factors



Hollow Fiber

- ✓ Ideal for liquids with low viscosity
- ✓ High packing density @ low footprint



Tubular


- ✓ Very efficient for highly viscous liquids
- ✓ Easy to install and clean



Spiral Wound


- ✓ Ideal for liquids with medium viscosity
- ✓ Element configuration is industry standard for many membrane types

2 Type & size of FO systems



Stand-alone FO

- ✓ Single pass system
- ✓ Suitable for proof of concept FO applications
- ✓ Ideal for process optimization where concentration of feed can be coupled to dilution of existing draw solution



Hybrid FO

- ✓ Draw regeneration using established water treatment methods



Lab-scale systems

- ✓ Proof of concept studies to assess technical feasibility
- ✓ Initial CAPEX/OPEX estimates to assess economic feasibility



Pilot scale systems

- ✓ Long term testing and process optimisation
- ✓ Fouling & cleaning investigation
- ✓ Full-scale plant feasibility assessment (CAPEX & OPEX)

3 Draw solutions and draw recovery methods

Draw solutions

- ✓ Select draw solute based on intended application (valuables concentration or wastewater dewatering)
- ✓ Draw solute must exhibit high solubility in water, high osmotic pressure and high diffusion coefficient
- ✓ Solute must be benign to FO membrane
- ✓ Low reverse solute flux and low viscosity

Draw solutions recovery methods

- ✓ Selection of draw recovery methods based on TDS
- ✓ Ensuring that osmotic pressure difference between feed and draw is maintained at a minimum of 10-15 bar
- ✓ Striking a balance between water recovery and draw recovery cost

Draw solute types	Examples	Advantages	Disadvantages
Inorganic salts	NaCl, MgCl ₂ , Na ₂ SO ₄ , (NH ₄) ₂ SO ₄	<ul style="list-style-type: none"> • High osmotic pressure • NF/RO for draw recovery • Low replenish cost 	<ul style="list-style-type: none"> • High reverse diffusion • Scaling precursor, like Mg²⁺, SO₄²⁻
Organic salts	Zwitterions (e.g. glycine) hydroacid complex	<ul style="list-style-type: none"> • Low reverse diffusion • NF for draw recovery 	<ul style="list-style-type: none"> • High replenish cost
Other organic compounds	Sucrose, fructose	<ul style="list-style-type: none"> • Suitable for most F&B applications • NF for draw recovery 	<ul style="list-style-type: none"> • High viscosity • Low osmotic pressure
Volatile compounds	NH ₄ HCO ₃ → NH ₃ + CO ₂	<ul style="list-style-type: none"> • High osmotic pressure • Waste heat for draw recovery 	<ul style="list-style-type: none"> • High reverse diffusion • Scaling precursor CO₃²⁻ • High ammonium content in product water
Other responsive solutes	Ionic liquid, glycol ether, nanoparticles, polymer	<ul style="list-style-type: none"> • Potentially lower energy consumption 	<ul style="list-style-type: none"> • Not commercialized

